

MAIN SIGNAL PATH IN PLAYBACK MODE
QR4014 MRN1404 (A.DUB Ⓗ :ON)
QR4006 MRN1404 (INSERT Ⓗ :ON)
QR4017 MRN1404 (POWER OFF Ⓗ :ON)
Q4015 2SD1328 (A.MUTE Ⓗ :ON)
QR4016 MRN1402 (S.SOUND Ⓗ :ON)
QR4001 MRN1404 (D.FM REC Ⓗ :ON)
QR4010 MRN1403 (DA REC Ⓗ :ON)
Q4002 2SB790 (REC : ON)
Q4003 MSB709 (FULL ERASE DRIVE)
QR4002 MRN1402 (REC Ⓗ :ON)
QR4005 MRN1402 (FULL ERASE Ⓗ :ON)
QR4003 MRN1403 (V.EE Ⓗ :ON)
QR4007 MRN1403 (PAL Ⓗ :ON)
IC4001 RC4565DD
T4001 EIQ7QF013Q
A.BIAS
VR4001 200KB
R CH Ⓛ
L CH Ⓛ
MODE SEL
MIX Ⓗ
TRICK Ⓛ
A.DUB Ⓗ
LP Ⓗ
S VHS CAS Ⓛ
INSERT Ⓗ
POWER OFF Ⓗ
A MUTE Ⓗ
D.FM REC Ⓗ
D.A REC Ⓗ
SAFETY TAB Ⓛ
REEL +B
S.SOUND Ⓗ
SSS Ⓛ
METER (L)
METER (R)
NTSC Ⓛ
FULL ERASE Ⓗ
REC Ⓗ
FM MUTE Ⓗ
NON SW 5V
A.H.SW
A.INPUT SEL A
A.INPUT SEL B
A.DUB P Ⓛ
FLY ERASE Ⓗ
TO SYSTEM CONTROL & SERVO SECTION (Page: 4-5/F-23)
REG 12.3V
TUNER AUDIO (N)
AUDIO OUT (R)
AUDIO +5V
AUDIO -5V
AUDIO OUT (L)
V.EE Ⓗ
SEL MUTE Ⓗ
NON SW 12V
AUDIO RFC OUT
UNREG -8V
TUNER AUDIO (R)
TUNER AUDIO (L)
AUDIO IN (R)
AUDIO IN (L)
REG 5V
PICTURE CTL
GND
TO LUMINANCE & CHROMINANCE SECTION (Page: 4-10/B-19, A-21)
P4004
H.P OUT (R)
H.P OUT (L)
GND (H.P)
PICTURE CTL
REC VR (L)
REC VR (C)
REC VR (R)
MIC Ⓗ
REG 12.3V
MIC IN
GND (MIC)
TO VR (Page: 4-43/E-23)
P4003
GND
FULL ERASE 12V
P4002
REG 5V
REC 12V
A.H.SW
GND
RF OUT
D.FM REC Ⓛ
REC IN
FLY ERASE Ⓗ
TO HEAD AMP P551 (Page: 4-39/E-10)
TP4511
TL A.RF
TL63
TL28
FE HEAD
T1401 EIQ7QF012Q
CR1401 EXED103Z333T
Q1401 2SD1991
P1502
GND
FULL ERASE 12V
L1401 100μ
FE HEAD C.B.A. (VEP00K88C)