



IC901
HD6433724A78H
SYSTEM CONTROL
P.P (S+P)

IC904
XRUS947AFS
CHARA. GEN

PG908

- 21 HI-B SW
- 22 VTR ON
- 23 CAM/LINE
- 24 TEST
- 25 REC RUN
- 26 REC LED
- 27 PB
- 28 S EDIT
- 29 MUTE
- 30 MONO
- 31 TAB SW
- 32 H STATE 0
- 33 H STATE 1
- 34 H STATE 2
- 35 TAPE STAGE
- 36 HE/MP
- 37 PB HB
- 38 NISC/PAL
- 39 HI-B MP
- 40 FADE
- 61 FE CONT.
- 62 REC HB
- 63 STROBE (S-CG)
- 64 ATF OUT
- 65 CLOCK (D-S)
- 66 DATA (D-S)
- 67 DATA (S-D)
- 68 CLOCK BUSY
- 69 CS (S-ATF)
- 70 DATA (S-CG)
- 71 CS (S-D)
- 72 UNLOAD
- 73 LOAD
- 74 A. Vcc
- 75 VTR KEY 1
- 76 VTR KEY 2
- 77 BATT.
- 78 SP/LP DET
- 79 ATF ERROR
- 80 DEW

IFOR H38E1
To EVF
CN2001
[P5-35]
IFOR H39E1
To EVF DRIVE
PG102
[P5-33]
IFOR H39E1

To MAIN (CHROMA)
[1L] - [7L]
[P5-30]

To MAIN (PREAMP)
[1E] - [3E]
[P5-25]

To MAIN (LUMA)
[1J] - [10J]
[P5-27]

To MAIN (TRUBLE SENSOR)
[1X] - [23X]
[P5-13]

To MAIN (JACK)
[1Y] - [21Y]
[P5-13]

Q912
2SD2216R (YR)

S902
HI-B SW
OFF
AUTO

Q918
UN9213 18CI
INV.

D919
MA132WK GND