



TO (2/6)

TO (3/4)

CN002 (D-1)

1	PCM OUT
2	PB RF
3	RF SWP
4	RF GND
5	REC ZCH
6	

CHECK PIN

• SIGNAL PATH

	VIDEO SIGNAL			AUDI SIGN/
	CHROMA	Y	Y/CHROMA	
REC	➡	➡➡	➡➡➡	➡
PB			➡➡➡	➡

REC REC/PB