



- | | | | |
|-----|---|-------|--|
| 751 | A-7040-419-A BASE (S) BLOCK ASSY, GUIDE | 773 | 3-965-648-01 SPRING (PINCH), TENSION |
| 752 | A-7040-418-A BASE (T) BLOCK ASSY, GUIDE | 774 | 3-965-579-01 ROLLER, PINCH PRESS |
| 753 | 3-965-559-01 STOPPER (T) | 775 | 3-965-563-01 GEAR, T SOFT |
| 754 | 3-965-557-01 STOPPER (T), GB | 776 | 3-965-565-01 CLAW, T SOFT |
| 755 | 3-965-558-01 STOPPER (S) | 777 | X-3945-397-1 DECK ASSY, REEL, S |
| 756 | 3-965-556-01 STOPPER (S), GB | 778 | X-3945-396-1 BAND ASSY, TENSION REGULATOR |
| 757 | 3-965-553-01 RAIL, GUIDE | 779 | 3-945-756-01 SCREW (M1.4X3) |
| 758 | 3-947-503-01 SCREW (M1.4X2.5) | 780 | 3-965-583-01 ARM, RVS |
| 759 | 3-965-573-01 RETAINER, TG4 | 781 | 3-965-580-01 SPRING, TENSION |
| 760 | 1-658-213-11 FP-355 FLEXIBLE BOARD | 782 | 3-966-384-01 SPRING, T SOFT |
| 761 | 3-965-552-01 HOLDER (T), SENSOR | 783 | 3-965-578-01 SPRING, TENSION |
| 762 | 1-657-786-11 FP-221 FLEXIBLE BOARD | 784 | 3-965-560-01 RATCHET, S |
| 763 | 3-965-551-01 HOLDER (S), SENSOR | 785 | 3-965-561-01 PLATE, RELEASE, S RATCHET |
| 764 | 1-658-214-11 FP-356 FLEXIBLE BOARD | 786 | X-3945-395-1 ARM ASSY, TG1 |
| 765 | A-7040-417-A ARM BLOCK ASSY, TG4 | 787 | 3-965-576-01 SPRING (TG1), TENSION |
| 766 | 3-965-574-01 SPRING, TORSION | 788 | 3-965-567-01 LID OPEN |
| 767 | 3-965-575-01 SPRING (PINCH), TORSION | 789 | 3-965-566-01 COVER, LS GUIDE |
| 768 | 3-965-568-01 GUIDE, LOCK | * 790 | 3-965-577-01 PLATE, CAM, LS |
| 769 | 3-965-562-01 SPRING (RATCHET), TENSION | 791 | 3-965-569-01 ARM, EJ |
| 770 | 3-965-581-01 RATCHET, T | 792 | A-7040-427-A LS CHASSIS ASSY (S1) |
| 771 | X-3945-394-1 ARM ASSY, PINCH | D001 | 8-719-988-42 DIODE GL453S |
| 772 | X-3945-398-1 DECK ASSY, REEL, T | S002 | 1-572-688-11 SWITCH, PUSH (1 KEY) (C. C. LOCK) |