



CN901

1	CAP VS
2	VTR UNREG
3	DRUM VS
4	LIGHT VCC
5	A/D KEY IN1
6	LIGHT VCC
7	LI-BATTERY
8	START/STOP
9	CAP ERROR
10	MOTOR GND
11	DRUM ERROR
12	MOTOR GND
13	VTR DD ON
14	CAM DD ON
15	STBY ON
16	EJECT
17	NC
18	SS GND
19	EVF 5V
20	SS GND
21	SS 5V
22	VIDEO GND
23	VIDEO 5V
24	VIDEO GND
25	DIG 5V(1)
26	CAM UNREG
27	DIG 5V(2)
28	CAM UNREG GND
29	CAM5V
30	DIG GND
31	CAM15V
32	CAM GND
33	CAM -8V
34	CAM GND

FROM/TO
SYSCON SERVO
CN502