



K3
K4
K2
K1



1	CAM GND	D901 4P (0-5)
2	CAM 4V	
3	CORE 4V	
4	0 4V	
5	0 5V	
6	CORE 4V	
7	CAM 5V	
8	0 5V	
9	CAM 5V	
10	CAM 5V	
11	EVF 5V	
12	CAM 15V	
13	UNREG GND	
14	EVF UNREG	
15	REG GND	
16	REG 5V	
17	V18 5V	
18	REG GND	
19	AU 5V	
20	V18 5V	
21	CAM ERR	
22	0 2 5V	
23	CAM VS	
24	CAM VS	
25	GRM VS	
26	GRM ERR	
27	MOTOR UNREG	
28	GRM VS	
29	V18 UNREG	
30	MOTOR UNREG	
31	UNREG GND	
32	UNREG GND	
33	V18 B/D DN	
34	CAM B/D DN	
35	LANC S10	
36	CAM DN	
37	CAM PWR SW COM	
38	LANC 0C	
39	0 OUT 0	
40	K OUT 1	
41	K OUT 5	
42	K IN 1	

(See
VS-121
CN