



CB MODEL: WITHOUT

INCH OPTION

LOC.	INCH	14 INCH	16 INCH	20 INCH	21 INCH
R258	DELETE	DELETE	1/BW 220M	1/BW 220M	1/BW 220M
R209	DELETE	DELETE	1/BW 2.4K/1/BW 2.4K/1/BW 10K	1/BW 10K	1/BW 10K
R215	1/BW 5.1K/1/BW 5.6K/1/BW 5.6K	1/BW 5.6K	1/BW 5.6K	1/BW 5.6K	1/BW 5.6K
C241	50V 221	50V 221	DELETE	DELETE	DELETE
C204	DELETE	DELETE	CH 47PF	CH 47PF	DELETE
C243	DELETE	DELETE	50V 100F	50V 100F	50V 100F
HC201	DELETE	DELETE	VL T 104	VL T 104	VL T 104

CF MODEL OPTION

LOCATION	BASIC MODEL	CF MODEL
R259	1/BW 270K	1/BW 130K
C261	10V 272	10V 102
C222	C-ELEC. 50V 0.47UF	C-ONLY 714
T201	ADS-10040	ADS-10056

SCHEMATIC DIAGRAM
 CHASSIS: SCT11D
 MODEL: CK5073Z, CK5073T
 BOARD NAME: MAIN
 FILE NAME: 0nech1p
 ONECHIP/CHROMA BLOCK