



(KV-G14P11)
TO V1 BOARD
CN 01

- R 1
- G 2
- B 3
- BLK 4
- GND 5
- S&A 6
- SCL 7
- ST-BY 8
- GND 9
- SSCP 10
- VIDEO 11
- 7V 12

- DGCT 1
- DGCT 2

- 2P WHT :MINI
- DGC 1
- DGC 2
- DGC 3

- CN602
- 2P :MINI

- CN601
- 2P WHT
- AC IN 1
- AC IN 2

(KV-G14M1)
(KV-G14S1)
TO F1 BOARD
CN1602

- CN608
- (KV-G14M01)
- TO F3 BOARD
- CN602
- 15V OUT 1
- GND 2
- ST-BY 3
- 15V IN 4

- CN609
- (KV-G14M01)
- TO F3 BOARD
- CN602
- GND 1
- NC 2
- 105V 3

- CN501
- XTAL 1
- NC 2
- GND 3
- BV 4

- CN860
- GND 1