


DEFLECTION SYSTEM ADJUSTMENT

1. Enter into service mode and select CXD 2018.
2. Select and adjust each item in order to get an optimum image.


CXD 2018

Item No.	Adjustment item	Data Amout
01	V SIZE	ADJ.
02	V SHIFT	ADJ.
03	S CORRECTION	ADJ.
04	V LINEARITY	ADJ.
05	H SIZE	ADJ.
06	PIN AMP	ADJ.
07	TILT	ADJ.
08	UPPER CORNER	ADJ.
09	LOWER CORNER	ADJ.
10	V BOW	ADJ.
11	ANGLE	ADJ.
12	HV COMP.V	13
13	HV COMP.H	8
14	FRAME SHIFT	OFF
15	FREE RUN 60 Hz	OFF
16	SYSTEM 60 Hz	OFF
17	ASPECT WIDE	OFF
18	DOUBLE SCAM	OFF
19	NON INTERLACE	ON
20	H SHIFT	32
21	N/S CORRECTION	ADJ.

V SIZE



V SHIFT




S CORRECTION




V LINEARITY




H SIZE




PIN AMP



TILT



UPPER CORNER PIN




LOWER CORNER PIN



V BOW



ANGLE



H SHIFT



N/S CORRECTION



3. Press **OK** button to write the data.

If menu display may disturb the adjustment press **⌫** to clear, to resume it, press **⌫** again.