

SERVICE DATA NUMBERS	MODE BUTTONS	SERVICE DATA NUMBERS	MODE BUTTONS
3n	OPERATE	06	PAUSE/STILL
01	EJECT	54	RESET
-0	INPUT SELECT	5	ZERO STOP
—	SPEED	49,40	INDEX
34,35	^ V, + -	A1,A2	TRACKING (+, -)/V-LOCK
—	CANCEL	—	PROG.
—	MENU	57	OSD
A4	TIMER REC	00	STOP
08	REC	03,02	FF, REW
—	ENTER	55	DISPLAY
—	SHOW VIEW/G-CODE	00	PLAY

Fig. D6 Service Data Display for Service mode 4