
(See Page 4-42)
TO AU-149 BOARD CN802
IC501
CXP80624A
MECHA
CONTROLER
IC504
ATF
CONTROLER
IC502
DRUM
DRIVER
LED SWITCH
ME/MP
SWITCH
(F-13)
TO SL-37 BOARD
W872
(See Page 4-68)
TO A-MECHA
(CAPSTAN MOTOR DRIVE)
(See Page 4-67)