

4-1 Preadjustment

4-1-1 Factory Mode

1. Do not attempt these adjustments in the Video mode.
2. The Factory Mode adjustments are necessary when either the EEPROM (IC902) or the CRT is replaced.
3. Do not tamper with the "Adjustment" screen of the Factory Mode menu. This screen is intended only for factory use.

4-1-2 When EEPROM (IC902) Is Replaced

1. When IC902 is replaced all adjustment data revert to their initial values. It is necessary to re-program this data.
2. After IC902 is replaced, warm up the TV for 10 seconds

4-2 Factory/Service Mode

4-2-1 Procedure for the "Adjustment" Mode

1. This mode uses the standard remote control. The Service Mode is activated by (1) pressing the "HIDDEN" service key on the local-keyboard, or (2) by entering the following remote-control sequence:

STAND-BY → P.STD → HELP → SLEEP → POWER ON
2. The "SERVICE (FACTORY)" message will be displayed. The Service Mode has four components: Adjustment, Test Pattern, Option Bytes and Reset.
3. Access the Adjustment Mode by pressing the "VOLUME" keys (▲, ▼). The adjustment parameters are listed in the accompanying table, and selected by pressing the CHANNEL keys (▲, ▼).

4-1-3 When CRT Is Replaced

1. Make the following adjustments AFTER setting up after setting up purity and convergence:

White Balance
Sub-Brightness
Vertical Center (VR302)
Vertical Size (VR301)
Horizontal Shift
2. If the EEPROM or CRT is replaced, set PSL and PVA to 15 and 63 (Factory Mode). Then use VR301 and VR302 to adjust V-Size and V-Center.

4. Selection sequences for the PAL system:

DOWN or UP key:
AGC>SBT>SCT>SCR>PDL>RC>GC>BC>RG>BG>PSL>PVS>PVA>PHS

5. Selection sequences for the NTSC system:

DOWN or UP key:
AGC>SBT>SCT>SCR>STT>NDL>RC>GC>BC>RG>BG>NSL>NVS>NVA>NHS

6. The VOLUME keys increase or decrease the adjustment values, which are stored in the non-volatile memory when Adjustment mode is cancelled.
7. Cancel the Adjustment Mode by repressing the "HIDDEN" key or the "STATUS" key.